

Installation Instructions

Step 1



Fit the PVC male waste adaptor to pipe outlet in wall, ensuring entire thread extends beyond finished wall lining

Connect trap to basin waste

Step 2



Measure extension tube from trap to wall connection, cut to required length and load bulkhead fitting, BSP nuts and sealing washers onto waste tube

Step 3



Remove trap from basin waste and connect extension tube assembly to trap outlet

Step 4



Re-attach trap to basin waste and connect extension tube outlet to the adaptor at the wall

Step 5



Test for water tightness and adjust chrome bulkhead cover to hide wall connection